



STIRLING

History and Development of the Stirling Cycle Cryogenerator

Dr. T. Bhowmick

Stirling Cryogenics India Pvt. Ltd.

Ir. R. Den Heijer

Stirling Cryogenics & Refrigeration BV

Contents




- Robert Stirling
 - Revival
 - Stirling Cryogenerators
 - The on going R&D
 - Applications
- The Organisation


Robert Stirling



- Cycle invented by Robert Stirling
- Alternative to regularly exploding boilers of steam engines
- Refrigeration with same cycle first discovered on 1832
- Both engine and cold generator discarded due to practical manufacturing problems



Rev Dr Robert Stirling (1790-1878)



Revival



- **1938**

Philips in need of power source for electricity generator for radiosets

Dr. Rinia's attention falls on 120 year old Stirling cycle

- **1940 – 1945**

Fuel shortage accelerates development


- **1948**

Dr. Koehler requested to investigate refrigeration aspects resulting in development of cryogenerator

Stirling Cryogenerators



- Research proves high efficiency of Stirling cycle in cryogenic temperature range compared to others



Stirling Cryogenerators




- Development and optimization of essential key element of Stirling cycle: **the regenerator**
- Temperature difference over approx 40 mm is more than 200 degrees
- High efficiency



Stirling Cryogenerators




- 1953
First commercial cryogenerator:
liquid air system
- Immediate success
- Increasing demand
for liquid nitrogen



Stirling Cryogenerators




- Development of compact air separation column
- Totally self regulating using thermo dynamical balance
- No moving part
- No electronic device
- Energy efficient = low LIN litre cost



Stirling Cryogenerators




Reliable regenerator and air separation column result in explosive market success



Stirling Cryogenerators




- 4 cylinder developed to meet increasing demand for cooling power
- High capacity air separation column developed to meet demand for LIN



Stirling Cryogenerators




Success results in new optimized systems



Stirling Cryogenerators



- Active Charcoal Pressure Swing Adsorption (PSA) replaces air separation columns and makes different capacities easily obtainable



Stirling Cryogenerators



- Large range meets many demands



The Present Status



Improvements

- Mean time between maintenance increased to 8000 operating hours.
- The control system is digitised with text display of operating status.
- Incorporation of capacity control for power efficiency
- Compact framed structure – ease of installation

Ongoing research


•Improving regenerators for even higher cold production



Mid 50's – mid 80's
Glued paper based
Copper wire filling




Mid 80's – mid 90's
Stainless steel construction
Copper wire filling



Mid 90's – now
Stainless steel construction
Sintered metal filling

Ongoing research

- High vacuum insulated head for more power



Ongoing research



- Improved chillers developed for rural areas with high temperatures
- Improvement in different maintenance related areas making maintenance easier and lowering operational cost
- Development of cold heat exchanger for specific application
- Oil free Stirling Cryogenerator.
- Stirling cycle based pulse tube for small capacity StirLIN plant.

The future machine of this decade



Cryosphere

- Magnetically driven dual piston system
- Low maintenance requirements
- Low power consumption
- Multi-purpose
- Compact and powerfull



On-going R&D projects



THE FUTURE LIQUID NITROGEN DISPENSER



StirLAB 200

Applications




Cryo Treatment of Metals

Why : Improvement of properties like hardness, abrasion resistance, life, dimensional stability.

Process : Stirling Cabinets.

Supply : Philips H&ST Factory
The Netherlands
TNI, Thuringen, Germany




Applications

Cooling High Temp. Superconducting devices

- With the invention and development of High Temp. Super Conductor over last decade, cooling temperature requirement got changed from 4K to 65K or higher.
- Achieving 65K can be through ;
 - *sub cooling liquid nitrogen
 - *boiling nitrogen at sub atmospheric pressure.
 - *combination of boiling & sub cooling.
- Option depends on specific requirement of application



Applications



[Hybrid Cooling System from Stirling NKT/DTU, Denmark](#)

Applications



- Artificial insemination
- Medicine
- Inerting
- Space
- Aeronautics
- Metal treatment
- Nuclear
- Food production and preservation
- Experimental physics
- Etc.....

Conclusion



Robert Stirling's invention has
lead to a successful cryogenic
business!

Stirling Cryogenics & Refrigeration BV



Mission:

**To provide low temperature cooling,
where you need it, when you need it.**

Address



Stirling Cryogenics & Refrigeration BV
Science Park, Eindhoven 5003
5692 EB SON, The Netherlands
www.stirling.nl

Registered Office in India

Stirling Cryogenics India Pvt. Ltd.
9th Floor AMBADEEP Building
14 Kasturba Gandhi Marg
New Delhi 110001

Regional offices at Mumbai, Kolkata & Chennai